












Schöck Isokorb® XT/T type A



XT/T
type A

Reinforced concrete – reinforced
concrete





Installation instructions



XT/T
type A

Reinforced concrete – reinforced
concrete

Installation instructions



XT/T
type A

Reinforced concrete – reinforced
concrete