

Gluing instructions for Conecto Park SL (elastomer):

1. The elastomer sections to be joined, must be evenly finished (precisely cut).
2. The place where the elastomers are glued should be cleaned by acetone solvent.
3. Apply glue on the cleaned surface (of the one section).
4. Push the two elastomer sections so adhesive joins them together.
5. The cut rubbers should be held in this position (pressed firmly) for about 2-3 minutes, until the glue finally dries.
6. After the adhesive dries, check the connection, put adhesive in places where quantity is insufficient.
7. Place the rubbers in the correct position and mount rest of the joint.